

## **NOTES:**

- 1. FOR INSTALLATIONS LESS THAN 3"
- 2. EQUIPMENT TO BE INSTALLED AT A MINIMUM OF 24" FROM ANY STRUCTURES OR HARDSCAPING.
- COVER BACKFLOW ASSEMBLY WITH POLAR BLANKET TO PREVENT FREEZE DAMAGE.
- 4. ENCLOSE ENTIRE BACKFLOW DEVICE WITH STRONG BOX BC-45-CR OR APPROVED EQUAL WHEN UNIT IS NEXT TO A STRUCTURE (I.E. WALL, BUILDING, ETC.) MOUNT TEST COCKS ON OPEN OR NON STRUCTURE SIDE.
- 5. ALL FITTINGS SHALL COMPLY WITH CALIFORNIA HEALTH AND SAFETY CODE, 116875 (NO LEAD BRASS)

## BACKFLOW PREVENTER ASSEMBLY DETAIL DRAWN BY: JSH CHECK BY: NBB SCALE: NONE CITY OF TURLOCK W-13 COUNCIL APPROVAL DEC, 2015